



1. Place hose fitting on push rod



2. Clamp hose in jaws



3. Pull handle



4. Assembly complete